

CARSON®

Attach-A-Mag™

Flexible Clamp-On LED Lighted Magnifier

Congratulations on selecting your new Carson LED Lighted Magnifier! In order to achieve optimum performance, please follow instructions for proper use and care.




AM-20

PRODUCT SPECIFICATION

Magnification:	2x	Dimensions:	4.3 in x 3.0 in x 12.0 in
Lens Diameter:	90mm (3.5")	Batteries:	3 G12 Batteries (included)
Weight:	0.36 lbs		


USING THE MAGNIFIER

1. Remove battery tab to activate batteries. Then slide switch to turn light ON/OFF.
2. Squeeze to open base clamp. Clamp onto table edge. Maximum width of base clamp is 1 3/4".
3. Bend and twist flexible arm as needed. Depending on your vision, you may need to move the magnifier closer or further away until focused.




REPLACING BATTERIES

1. Hold the outer rim of the magnifying lens with one hand. With the other hand, pull battery compartment to remove from magnifier.



2. Use a Phillips #0 screwdriver to remove safety screw from battery door. Insert three new G12 button cell batteries according to polarity indicators marked on battery door. Reattach battery door and safety screw. Return battery compartment to magnifier.



BATTERY WARNING

Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Insert in direction indicated. Discard button cell batteries carefully. Keep button cell batteries away from children.

CARE

Clean using microfiber lens cloth. Do not use any abrasives, chemical cleaners, or solvents.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

For warranty information, visit www.carson.com/warranty

www.carson.com

Carson Optical 2070 5th
Avenue, Ronkonkoma, NY
11779 | Tel: 631-963-5000